

Location of the coolant Recovery Rank can vary based on vehicle and personal preference. Below are instructions for proper installation:

1. Pick a location and test fit for clearance. Bottle dimensions: H(w/cap) 5 1/2" x W 3 3/4" x D 1 7/8"
2. Connect the hose provided to the radiator overflow and secure with hose clamp.
3. Look at diagram above and select your preferred hose-set up. Drill out the nipple on the bottle that best suits your preferred set-up using a 1/8" drill bit. Clean the debris from the bottle and push hoses on and secure with hose clamps.
4. Put the bottle in place and secure with straps provided. Make sure the straps are snug so that the bottle will not move around and cut off excess strap.
5. Installation is now complete.