

HANDLE

Assembly:

After removing the old handles, clean the handlebar ends and gas handle with clean alcohol or other alcohol-based solvent. Clean and apply clean alcohol to the inside of the handle and then push the handle all the way to the end of the handlebar. Do not use soap, oil or petrol. Wait approximately 2 hours before using the motorcycle with the newly fitted grips. If handlebar glue is included, follow these instructions: apply approx. 8mm of glue to the end of the handlebar and to the inside of the handlebar. Loosely slide the handle onto the end of the handlebar. Wipe off the rest of the glue.

Warning:

Use in a well-ventilated room. Avoid prolonged inhalation of adhesive or skin contact. The adhesive contains white spirit and less than 5% methanol. If glue is swallowed, do not induce vomiting but call a doctor immediately.

Maintenance.

Riding a motorcycle can be dangerous and using the handles will not prevent injury. The manufacturer is not responsible for injuries that may occur.

Environmentally dispose of the product at the end of its useful life.

Made in the EU

Imported by MEFO SPORT CENTRUM s.r.o., Jinín 60, Strakonice, www.mefo.cz