

Trapeze guard with motorcycle clocks

Switching on:

Press "S "+"M" to turn on the clock. The "M" button is used to switch functions.

Clock:

Hold "S" to activate the settings, click "S" to add units. Press "M" to toggle between minute/hour. After setting the time, wait without pressing, or press "M "+"S" to save the settings.

Stopwatch:

Press "S" to activate the stopwatch. Subsequently press "S" to stop the time. Holding down "S" resets the stopwatch.

Timer:

Press and hold "S" to activate the setting. Press "S" to add a unit. "M" is used to switch between hour and minute. After selecting the time, wait and the selection will be confirmed. Press "S" to start/stop the timer. Restart is by pressing "S". TOT: Total time the bike has been started. With the clock on, it is loaded automatically. JOB/1: Current time travelled. Can be reset. Pressing "S" restarts the time. SVC: Maintenance interval. Holding "S" activates the menu settings. The "M" and "S" buttons move the units up and down. After selecting the time (in hours), just do not press anything and the time will be set. When the time has elapsed, the display will flash. Sen-: Holding down "S" activates the vibration sensitivity menu. Use "M" and "S" to move through the menu to see how sensitive you want the clock to be.

Off:

Holding "M "+"S" will cause "Loc" to appear on the clock and then the clock will turn off. It does not turn off automatically and the clock must be turned off during transport. When the clock is switched on, it can read MTH even during transport.

Dispose of the product environmentally at the end of its life.

Made in the EU

MEFO SPORT CENTRUM s.r.o. Jinín 60, Strakonice 38601, www.mefo.cz